

# Kodak White Background Accessory for i600/i1800 Series Scanners

A-61576\_EN  
Part No. 9E4559  
October 2006  
CAT No. 835 3807

If you are scanning translucent documents, the *Kodak* White Background Accessory will reduce black background bleed-through, which produces whiter images. To order this accessory, use catalog number 894 9000.

## NOTES:

- When the White Background Accessory is installed, you cannot perform the following functions: automatically detect, automatically detect and straighten or image calibration.
- The following photos may vary slightly depending on your scanner model.



Image without  
White Background  
Accessory



Image with  
White Background  
Accessory

The White Background Accessory includes two white background strips that replace the black background strips in the scanner. Do not discard the black background strips, as these must be placed back in the scanner for calibration.

To install the White Background Accessory:

1. Turn the scanner off.
2. Open the pod.
3. Remove the upper black background strip by grasping the green tab and firmly pulling the strip away from the scanner.



4. Take one of the strips included with the White Background Accessory and put it in place of the black background strip that you removed.
5. Remove the lower black background strip by grasping the green tab and firmly pulling the strip away from the scanner.
6. Take the other strip and put it in place of the black background strip that you removed.
7. Close the pod.
8. Power up the scanner and restart the host computer so the White Background Accessory will be properly recognized by the system.

EASTMAN KODAK COMPANY  
Document Imaging  
Rochester, NY 14650

Kodak is a trademark.



DOCUMENT  
IMAGING

INNOVATION YOU CAN COUNT ON™