





General Consumables for ALL Kodak Scanners

The consumables listed below are for use with all *Kodak* Scanners.









Please see individual scanners for consumables and accessories specific to your model.

CAT No.	Description
853 5981 	Kodak Digital Science Roller Cleaning Pads (24 per package) Usage: approximately one pad per day or more frequently if required.
169 0783 	Kodak Digital Science Transport Cleaning Sheets (50 sheets per package) Usage: 2 to 4 sheets per 8-hour shift/machine.
896 5519 	Staticide Wipes / for Kodak Scanners (6 boxes of 24) Usage: approximately 1 per day. Staticide Wipes are NOT available in Europe, Africa and the Middle East. Order Brillianize Detailer Wipes / for <i>Kodak</i> Scanners, CAT No. 826 6488, (see below for a description) as a replacement for Staticide Wipes.
826 6488 	Brilliance Detailer Wipes / for Kodak Scanners Includes: 12 dual packets with a microfiber cloth Usage: these cleaning pads are an alternative to the Staticide wipes for cleaning and polishing of the scanner's image guides when scanning in color. Do not use this wipes on the feeding or transport rollers.

NOTE: Staticide Wipes are not for use with the *Kodak* Picture Saver Scanning System / PS400/PS800; *Kodak* Picture Saver Scanning System PS450 or the *Kodak* s1220 Photo Scanning System.



Kodak i1400 Series Scanners

CAT No.	Description
124 1066 	Kodak Feeder Consumables Kit / for i100/i200/i1400 Series Scanners Includes: 1 feeder module, 1 separation module, 2 pre-separation pads, 24 replacement tires Usage: See the table on the next page for a guideline on how often to change consumables.
Also available in <i>Extra Large size</i> 821 5808	Kodak Extra Large Feeder Consumables Kit / for i100/i200/i1400 Series Scanners Includes: 5 feed modules, 5 separation modules, 10 pre-separation pads, 120 replacement tires Usage: See the table on the next page for a guideline on how often to change consumables.
197 8253 	Kodak Imaging Guide Set for i1400 Series Scanners Includes: 1 upper guide, 1 lower guide Usage: replace when damaged or scratched.
135 5155 	Document Printer: Ink Cartridges / Black Includes: 10 cartridges Usage: approximately 350,000 to 450,000* characters per ink cartridge. NOTE: If you have the Enhanced Printer, order CAT No. 818 3386.
840 5425 	Document Printer: Ink Blotters Includes: 60 blotters Usage: replace when there is a build-up of ink.
826 7486 	Document Printer: Ink Cartridge Carrier Usage: purchase this item if you want to use the print function on the i1420 or i1440 Scanner. NOTE: If you have the Enhanced Printer, order CAT No. 113 3842.
818 3386 	Enhanced Printer: Black Ink Cartridge Includes: 9 cartridges (3 packs of 3) Usage: approximately 1,200,000 to 1,700,000* characters per ink cartridge.
159 6832 	Enhanced Printer: Red Ink Cartridge Includes: 9 cartridges (3 packs of 3) Usage: approximately 1,200,000 to 1,700,000* characters per ink cartridge..
113 3842 	Enhanced Printer: Ink Cartridge Carrier Usage: purchase this item if you want to use the print function on the i1420 or i1440 Scanner. NOTE: If you have the Document Printer, order CAT No. 826 7486.
185 1435	Kodak i1400 Scanner External Power Supply
161 3637	Kodak i1400 Scanner Power Cord Kit

* Based on font size being used.

Feed Module and Separator Module Guidelines for the Scan Station 500/700, s1220 Photo Scanner, PS400/PS800/PS450/PS50/PS55/PS80 Scanners, i2400, i2600, i2800 Scanners and the i100 / i200 / i1200 / i1300 / i1400 Series Scanners Consumables Kits

The following table provides a guideline of how often to change the feed module, separation roller, pre-separation pad and tires.

- **Feed module and separation roller tires:** tire life will vary depending upon paper types, environment and cleanliness. Nominal tire life is approximately 125,000 pages, results will vary. Degradation of feeder performance, multiple feeds, stoppages, etc. indicate a need to change tires. Change all tires on the feed module and separation roller at the same time.
- **Feed module and separation roller:** it is recommended that you install a new feed module and separation roller approximately every 4th tire change. Install a new feed module and separation roller at the same time.
- **Pre-separation pad:** change every other time you change the feed module, separation roller or change the tires.

NOTE: The replacement tires are for use with the feed module and the separation roller.

Description	Kodak Feed Rollers	Feeder Consumables Kit	Extra Large Feeder Consumables Kit
	CAT No. 148 4864	CAT No. 124 1066	CAT No. 821 5808
For use with these scanners	Scan Station 500/700 PS400/PS800/PS450/PS50/ PS55/PS80/s1220 i2400/i2600/i2800 i1200/i1300	i100, i200, i1400 Series Scanners	
Feed Modules (4 tires)		1	5
Separation Rollers (2 tires)		1	5
Pre-Separation Pads	2	2	10
Replacement Tires	12	24	120
Expected scans / kit	250,000	500,000	2,500,000